Waste Guidelines for Project Generated Waste

The Department of Environment Health and Safety (EHS) handles all Cornell-owned hazardous waste, depending on quantity. If the quantity is too large, EHS will coordinate disposal through an external vendor.

N2

DESIGN PHASE

Building clean out: remove all chemical waste, radiological waste, and regulated medical waste. Facilitated by the building coordinator and EHS.

Asbestos Survey: Is asbestos present? If yes, contact EHS Industrial Hygiene unit for assistance.

Hazardous Material Survey:

Lead, PCBs, and Radiation, conducted by consultants.

PRE-CONSTRUCTION Kick-Off Essentials

<u>Contractor Waste Material</u> <u>Disposal Form</u>: complete the form and submit to EHS for approval.

Hazardous Waste Plan: if hazardous waste is present, develop a disposal plan and cost estimation with EHS.

ð

οχις

FUEL

- 03

WASTE STREAMS

Universal Waste: intact mercury thermometers, fluorescent bulbs, batteries, light ballasts (non PCBs), glycol, used oil. Managed by * R5 Recycling or by the contractor.

Hazardous Waste: chemical solvents, contaminated oil, mercury contaminated sink traps, broken mercury devices, PCBs, lead based paint, broken fluorescent bulbs, smoke detectors with radioactive isotopes. *Managed by * EHS.*

Waste Containers for these are available upon request.

DOL (non-RCRA) Regulated Waste: asbestos is managed by the abatement contractor.

SPILL CONTROL

Type of Spills: gas, hydraulic oil, diesel, antifreeze, asbestos (1 lb or more), chemicals or suspect unknown materials.

Action: call CUPD to dispatch Cornell EHS emergency services at 607-255-1111.

> Questions? Visit: EHS.Cornell.edu AskEHS

Asterisk indicates a paid service.

Contacts: Luke Thomas, EHS - ltt26@cornell.edu | Jaron Khoury, HazMat - jk2925@cornell.edu | Chris Mott, R5 Recycling - ctm65@cornell.edu